

ECLIPSE WINDOW FILM PREP, INSTALL AND CARE INSTRUCTIONS

READ BEFORE INSTALLATION

If at any time during the installation, a product quality or installation issue should be discovered, STOP! Contact Takeform before proceeding.

Tool Recommendations:

- Felt Tipped Squeegee
- Lint Free Cloth
- Tape Measure
- Razor Knife
- Level
- Ammonia free glass cleaner (ex: Sprayway) for cleaning windows

Before Installation:

- Inspect packaging upon receipt for damage. Immediately file a claim with the carrier if damage is found. Also, contact Takeform regarding the issue.
- After opening, check to assure that all product has been received.
- Allow the product to acclimate to room conditions for 48 hours prior to installation.

Surface Preparation:

- Surface must be flat, smooth, clean and dry.
 - Applicable surfaces are glass, acrylic, polycarbonate, metal and painted metal.
- Pay extra attention to cleaning rubber seals surrounding window as these tend to secrete oils and create failures if not cleaned sufficiently.
- Install method is dry.
- Eclipse window film is acceptable for indoor and outdoor use.
 - Eclipse is primarily used for exterior applications, allowing an image to be seen on outside of glass while providing viewing through film perforations from inside.
- Install temperature must be 40°F to 100°F (not in direct sunlight).
- Surface with anti-graffiti coating is not acceptable for window films.
- Do not install directly above or next to heating sources (i.e., heater or radiator).
- Do not install window films on top of each other.

Installation:

- Carefully remove liner from backside.
- If window film butts to edge of window trim, typically a 2" bleed is included along left, right and bottom (top to be flush cut). Any installation requirements specified along edge of print or on a sticker attached to liner on back supersedes this.
- Using squeegee, start from a corner (typically upper left) and work outward away from corner.
- Using a razor knife with a new blade, trim any bleed along the edges.
- Clean using recommended cleaners and wipe with a lint free cloth.
- If multiple pieces of film are required to cover a single area, the seams are to be butt-seamed, thus no seam cutting required.
- Window films may take up to 24 hours to fully adhere to the installation surface.

Care and Maintenance:

- Recommended cleaners: Mild soap (i.e., Dawn® or Joy®) and water solution.
- When cleaning, spray into a dry, clean, lint free cloth and wipe clean. Do not scrub. Rinse with fresh water to remove any residue, then wipe dry.
- Ordinary dirt smudges and most grime can be removed with a mild soap and water solution.
- Remove stains promptly to prevent any reaction between the stain and the graphic that could cause discoloration.
- Do not use steel wool, powdered abrasives, or abrasive sponges.
- Do not use any cleaners containing alcohol or bleach.

Eclipse (WF-301) Specifications:

- Material: 6 mil white/black micro-perforated 60/40 (40% transparency) vinyl film with pressure sensitive adhesive
- Use: Indoor and outdoor
- Adhesive: pressure sensitive, permanent